

# **USE CARE TO PREVENT INJURY.**

### COMPLY WITH THE FOLLOWING TO AVOID SERIOUS PERSONAL INJURY.

- 1. Guards must be provided on all power transmission and conveyor applications in accordance with provisions of ANSI/ASME B 15.1 1992 and ANSI/ASME B 20.1 1993 or other applicable standards. When revisions of these standards are published, the updated edition shall apply.
- 2. Always lock out power switch before installing, removing, lubricating or servicing a system that uses Cam Clutch products.
- 3. If the Cam Clutch is used for repeated starting and stopping, make sure the strength of the supports for the Cam Clutch are sufficient.
- 4. The capacity of your Cam Clutch may be effected by the accuracy of its set up, the amount of pressure exerted on it, wear on other parts in your system, or wear life of the Cam Clutch itself. Check the Cam Clutch at regular intervals and take any necessary safety precautions.

TSUBAKIMOTO SINGAPORE PTE, LTD.

25 Gul Lane

Singapore 629419

Phone : 68610422/3/4

TAIWAN TSUBAKIMOTO CO.

Phone : 03-3293827/8/9

TSUBAKI EMERSON CO.

Phone : 02-2325-9555

Facsimile : 02-2784-0022

Facsimile : 03-3293065

TAIWAN BRANCH

Taiwan R.O.C.

Kuei Shan-Hsiang, Taoyuan-Hsien

5th F1., No. 2, Jen Ai Road, Sec.4, Taipei

Facsimile : 68617035

No. 7 Feng Sun Keng

Taiwan R.O.C.

Jurong

When connecting or disconnecting Cam Clutch products, eye protection is required. Wear safety glasses, 5. protective clothing, gloves and safety shoes



# **TSUBAKI EMERSON CO.**

#### Group Companies: U.S. TSUBAKI, INC. 301 E Marguardt Drive

Wheeling, IL 60090 U.S.A. 847-459-9500 Phone Facsimile : 847-459-9515

### TSUBAKI of CANADA LIMITED 1630 Drew Road

Mississauga, Ontario, L5S 1J6 Canada Phone 905-676-0400 Facsimile : 905-676-0904

TSUBAKI AUSTRALIA PTY. LTD. Unit E. 95-101 Silverwater Road Silverwater, N.S.W. 2128 Australia : 02-9648-5269 Phone Facsimile : 02-9648-3115

### TSUBAKIMOTO (THAILAND) CO., LTD. Room No. C, T.W.Y. Office Center 10th Floor, Serm-Mit Tower, 159 Soi Asoke, Sukhumvit Road, North-Klongtoey Wattana, Bangkok 10110 Thailand

: 66-2-261-9991/2 Phone Facsimile 66-2-261-9993

Distributed by:

1-1, Kotari-Kuresumi, Nagaokakyo, Kvoto 617-0833, Japan Internet: http://www.tsubaki-emerson.co.jp/english/

TSUBAKIMOTO EUROPE B.V Belder 1 4704 BK Boosendaa The Netherlands

: (075) 957-3131

Facsimile: (075) 957-3122

Phone

Phone : 0165-594800 Facsimile : 0165-549450

### TSUBAKIMOTO U.K. LTD.

Osier Drive, Sherwood Park Annesley, Nottingham, NG15 ODX United Kingdom Phone : 01623-688788 Facsimile : 01623-688789

> TSUBAKIMOTO CHAIN CO. Shanghai Representative Office 603 Unicom International Tower 547 Tianmu Xi Road, Shanghai, China 200070 Phone : 021-6317-1662 Facsimile : 021-6317-0794



# **TSUBAKI EMERSON** BACKSTOP **CAM CLUTCHES BSEU & BS** SERIES







# **BACKSTOP CAM CLUTCH**



### **Dimensions and Capacity**

	Stock Bore Size		Torque	Max.							_			_			H-M	
Model	Dia	Keyway	Capacity	Overrun.	D	D2	LI	L2		В	F	a	N	E	J	D1	x Size x Pich	Weight
	H7		N∙m	r/min	mm	mm	mm	mm	mm	mm	mm	mm	mm	mm	Chamfer	mm		kg
BSEU25-20	20	6 × 2.8	216	500	83	42	35	_	12	40	90	15	35	5	1.5			1.00
BSEU25-25	25	8 × 3.3	216	500	83	42	35		12	40	90	15	35	5	1.5	_		0.95
BSEU40-20	20	6 × 2.8	1,440	450	118	60	55	_	15	40	110	15	35	8	1.5	_		3.73
BSEU40-25	25	8 × 3.3	1,440	450	118	60	55	—	15	40	110	15	35	8	1.5	_		3.65
BSEU40-30	30	8 × 3.3	1,440	450	118	60	55	_	15	40	110	15	35	8	1.5	_	—	3.56
BSEU40-35	35	10 × 3.3	1,440	450	118	60	55	—	15	40	110	15	35	8	1.5	_		3.45
BSEU40-40	40	12 × 3.3	1,440	450	118	60	55	_	15	40	110	15	35	8	1.5	_		3.32
BSEU70-45	45	14 × 3.8	3,140	350	165	90	59	_	20	80	140	18	35	10	1.5	_	—	7.44
BSEU70-50	50	14 × 3.8	3,140	350	165	90	59	_	20	80	140	18	35	10	1.5	_	—	7.28
BSEU70-55	55	16 × 4.3	3,140	350	165	90	59	—	20	80	140	18	35	10	2.0	_	—	7.09
BSEU70-60	60	18 × 4.4	3,140	350	165	90	59	_	20	80	140	18	35	10	2.0		—	6.88
BSEU70-65	65	18 × 4.4	3,140	350	165	90	59	_	20	80	140	18	35	10	2.0		—	6.68
BSEU70-70	70	20 × 4.9	3,140	350	165	90	59	_	20	80	140	18	35	10	2.0	_	—	6.43
BSEU90-75	75	20 × 4.9	4,700	250	190	120	63	_	20	80	165	20	40	15	2.0	_	—	10.10
BSEU90-80	80	22 × 5.4	4,700	250	190	120	63	_	20	80	165	20	40	15	2.0	_		9.82
BSEU90-85	85	22 × 5.4	4,700	250	190	120	63	_	20	80	165	20	40	15	2.0	_		9.57
BSEU90-90	90	25 × 5.4	4,700	250	190	120	63	_	20	80	165	20	40	15	2.0	_		9.23
BS 95- 95	95	25 × 5.4	7,840	150	230	130	110	115	—	_	_	—	_	_	2.0	200	6 × M14 × P2.0	29.4
BS110-100	100	28 × 6.4	10,800	150	270	150	110	115	_	_	_	—	_	_	2.0	220	6 × M16 × P2.0	35.7
BS110-105	105	28 × 6.4	10,800	150	270	150	110	115	_		_	—	_	—	2.0	220	6 × M16 × P2.0	35.0
BS110-110	110	28 × 6.4	10,800	150	270	150	110	115	—			—		—	2.0	220	6 × M16 × P2.0	34.2
BS135	90 to 135	_	15,700	100	320	180	130	135	_	_	_	_	_	_	_	280	8 × M16 × P2.0	68.0
BS160	100 to 160		24,500	100	360	220	130	135	—		_	—	_	_	_	315	10 × M20 × P2.5	85.6
BS200	100 to 200	_	37,200	100	430	265	145	150	_		_	—	_	_	-	380	8 × M22 × P2.5	140.0
BS220	150 to 220		49,000	80	500	290	230	235	—			—	_	_	_	420	16 × M20 × P2.5	263.5
BS250	180 to 250		88,200	50	600	330	290	295	—			—	_	—	_	530	16 × M24 × P3.0	580.0
BS270	200 to 270		123,000	50	650	370	290	295	_		_	—		_	_	575	16 × M24 × P3.0	620.0
BS300	230 to 300	_	176,000	50	780	470	290	295	_	_	_	_	_	_	_	690	16 × M30 × P3.5	850.0
BS335	250 to 335		265,000	50	850	495	320	305	_	_	_	_	_	_	_	750	16 × M36 × P4.0	1,135
BS350	250 to 350	_	314,000	50	930	535	360	320	_	_	_	—	_	_	_	815	16 × M36 × P4.0	1,605
BS425	325 to 425	_	510,000	50	1,030	635	450	440	_	_	_	—	_	—	-	940	18 × M36 × P4.0	2,450
BS450	350 to 450		686,000	50	1,090	645	480	450	_	_	_	—	_	_	_	990	18 × M42 × P4.5	2,820

# **BACKSTOP CAM CLUTCH**

## **Explanation 1**

The Tsubaki Backstop Cam Clutch, a one-way clutch with the safest reverse rotation prevention qualities available, was manufactured mainly for installation on the low speed shaft of inclined conveyors or bucket elevators. The backstop cam clutch as well as all other Tsubaki Cam clutches is a one-way, sprag type clutch. Compared to other one-way clutches (ratchet or roller ramp clutch) similar in size, overheating during times when the motor is idling is significantly lower. This helps maintain superb lubrication qualities thereby improving the wear life of the clutch. Extended fatigue life is also obtainable due to the clutch's large torque capacity. Both the European style BSEU series, as well as the BS series cam clutch which boasts of thirty years of reputable performance since its introduction, can be used as reverse rotation prevention cam clutches for an array of conveyor sizes. Applicable shaft sizes range from  $\phi 20 \sim \phi 450$  mm. Please refer to "TSUBAKI CAM CLUTCHES" (catalog no. 5111) for details on the BS series.

## Installation and usage for BSEU series

- 1. We recommend using a shaft tolerance of h7 or h8 for Cam Clutch installation.
- 2. DIN6885.1 keyway is standard.
- 3. Before installation, verify that the direction of rotation of the inner race of the Cam Clutch (shown by the arrow on the inner race) is the same as the direction of rotation of the conveyor.
- 4. When inserting the Cam Clutch on the shaft, apply pressure only on the surface of the inner race with a soft hammer. Never strike the Cam Clutch with a steel hammer or apply unnecessary impact loads.
- 5. Always use a parallel key for installation onto the shaft and then fix the Cam Clutch to the shaft with the end plate. Never use a tapered key. Allow for a clearance between the top of the clutch keyway and the top of the key for pressure ventilation. A pressure ventilation hole is provided on the keyway of the clutch's inner race.



## Explanation 2

Other Possible Applications:

BSEU Series Cam Clutches may also be used for low frequency indexing applications. A maximum indexing frequency of no more than 50 cycles/min. and a safety ratio of 2.5 times higher than the working torque are required. Be sure that the stress applied to the torque arm functions at a right angle in relation to the shaft direction. If the stress that is applied to the torque arm is set diagonally, the inner parts of the clutch will entangle causing damage and drastically reduce the operational life of the Cam Clutch.

- 6. Use the frame or a pin to eliminate outer race rotation.
- 7. Set a 0.5 mm degree clearance between the torque arm and the frame (torque arm stopper) or the long slit in the torque arm and the pin. If the torque arm is rigidly mounted, it will apply a load to the Cam Clutch which may eventually damage it.
- 8. The Cam Clutch is pre-packed with low temperature grease before shipment and is ready for installation and operation. No lubrication maintenance is required. The ambient operational temperature range is –40° to 50°C. However, the maximum temperature should be determined depending on the number of shaft revolutions. Further, if the number of shaft revolutions is low, a higher ambient operational temperature range is allowable. Consult with Tsubaki for more details.

